

6" RADIUS CORNER ASSEMBLY

PLACE THE 6 INCH RADIUS INSERT BETWEEN THE END OF PANEL AND THE CORNER BRACKET

