

Place a brace centered on each joint for clip installation. Use TEK screws every 12-18" to secure coping to top of panel. Place braces every 12-18" and secure with TEK screws. Braces can be spaced at 24" on radius sections.



