
CHAMBERLAIN GAME TABLES


ASSEMBLY INSTRUCTIONS FOR FOOSBALL TABLE




PG-4007/PG-4034

Parts List


	140	110	
#1	#2	#3	#4
Main Cabinet 1 piece	leg 4 pieces	End Leg Panel 2 pieces	Side Leg Panel 1 piece
#5	#6	#7	#8
Tw o Player Rod 2 pieces	Three Player Rod 4 pieces	Five Player Rod 2 pieces	5/8"X38MM plastic Washer 16 pieces
#9	#10	#11	#12
Visit players	Home players	8#X1" Screw	Lock Nut
13 pieces	13 pieces	26 pieces	26 pieces
#13	#14	#15	#16
Rod Handle 8 pieces	Bumper 16 pieces	T5x15mm Screw 8 pieces	Rod end cap 8 pieces
#17	#18	#19	#20
F4X1/2" Screw 2 pieces	Ball entry cup 2 Set	5/16"X1-1/2" Bolt 8 pieces	5/16"X2-1/4" Bolt 4 pieces
#21	#22	#23	#24
5/16"X4-3/4" Bolt 8 pieces	5/16" Washer 20 pieces	5/16" Washer 20 pieces	Ball 2 pieces



Step 1:



Step 2:



Step 3:

